



NOTE: -

1. Number of motor(s) and location depends on curtain overall dimension
2. Minimum 5 sides required
3. Number of sides depends on radius and ceiling slot width



Edward House, Penner Road,
Havant, Hampshire, PO9 1QZ, UK
Tel: +44 (0) 23 9245 4405
Fax: +44 (0) 23 9249 2732
Email: info@coopersfire.com
Web: www.coopersfire.com

DRAWN:	TITLE:	
ML	FireMaster® Concertina™ - Circular Typical Arrangement	
CHECKED:	© 1997-2018 A COOPER GROUP LIMITED ALL RIGHTS RESERVED. THIS DESIGN MAY NOT BE REPRODUCED IN ANY MATERIAL FORM INCLUDING ELECTRONICALLY WITHOUT THE WRITTEN PERMISSION OF THE COPYRIGHT NAMES	
JR	ALL DIMENSION IN MILLIMETERS UNLESS OTHERWISE STATED	
APPROVED:	DRG. No.	ISSUE:
JR	604/003/MK	1
		DATE: 15.05.2018

HEADBOX		Z (mm)	CURTAIN DIMENSION		
X (mm)	Y (mm)		RADIUS	DROP	NO OF ANGLE
350	225	100	Unlimited	< 4m	Min. 5
350	300	175	Unlimited	< 8m	Min. 5